

COOLING AND LUBRICATION SYSTEM

CONTENTS

ENGINE COOLANT	5- 2
COOLING CIRCUIT	5- 3
COOLING CIRCUIT INSPECTION	5- 3
RADIATOR	5- 4
REMOVAL	5- 4
INSPECTION AND CLEANING	5- 5
INSTALLATION	5- 6
RADIATOR RESERVOIR TANK	5- 6
REMOVAL/INSTALLATION	5- 6
RADIATOR CAP	5- 6
INSPECTION	5- 6
WATER HOSE	5- 7
INSPECTION	5- 7
COOLING FAN	5- 8
REMOVAL	5- 8
INSPECTION	5- 8
INSTALLATION	5- 8
COOLING FAN THERMO-SWITCH	5- 9
REMOVAL	5- 9
INSPECTION	5- 9
INSTALLATION	5- 9
ENGINE COOLANT TEMPERATURE SENSOR	5-10
REMOVAL	5-10
INSPECTION	5-10
INSTALLATION	5-10
THERMOSTAT	5-11
REMOVAL	5-11
INSPECTION	5-11
INSTALLATION	5-12
WATER PUMP	5-13
REMOVAL AND DISASSEMBLY	5-13
INSPECTION	5-15
REASSEMBLY AND INSTALLATION	5-15
LUBRICATION SYSTEM	5-18
OIL PRESSURE	5-18
OIL FILTER	5-18
OIL PRESSURE REGULATOR	5-18
OIL STRAINER	5-18
OIL JET	5-18
OIL PUMP	5-18
OIL PRESSURE SWITCH	5-18
OIL COOLER	5-18
REMOVAL	5-18
INSPECTION AND CLEANING	5-19
INSTALLATION	5-19
ENGINE LUBRICATION FLOW CHART	5-20
ENGINE LUBRICATION CIRCUIT	5-21

ENGINE COOLANT

At the time of manufacture, the cooling system is filled with a 50:50 mixture of distilled water and ethylene glycol anti-freeze. This 50:50 mixture will provide the optimum corrosion protection and excellent heat protection, and will protect the cooling system from freezing at temperatures above -31°C (-24°F).

If the motorcycle is to be exposed to temperatures below -31°C (-24°F), this mixing ratio should be increased up to 55% or 60% according to the figure.

CAUTION

- * Use a high quality ethylene glycol base anti-freeze, mixed with distilled water. Do not mix an alcohol base anti-freeze and different brands of anti-freeze.
- * Do not put in more than 60% anti-freeze or less than 50%. (Refer to Right figure.)
- * Do not use a radiator anti-leak additive.

50% Engine coolant including reserve tank capacity

Anti-freeze	1 100 ml (2.3/1.9 US/lmp.pt)
Water	1 100 ml (2.3/1.9 US/lmp.pt)

Anti-freeze density	Freezing point
50%	-31°C (-24°F)
55%	-40°C (-40°F)
60%	-55°C (-67°F)




Fig.1 Engine coolant density-freezing point curve.





Fig.2 Engine coolant density-boiling point curve.

WARNING

- * You can be injured by scalding fluid or steam if you open the radiator cap when the engine is hot. After the engine cools, wrap a thick cloth around cap and carefully remove the cap by turning it a quarter turn to allow pressure to escape and then turn the cap all the way off.
- * The engine must be cool before servicing the cooling system.
- * Coolant is harmful;
 - If it comes in contact with skin or eyes, flush with water.
 - If swallowed accidentally, induce vomiting and call physician immediately.
 - Keep it away from children.

COOLING CIRCUIT



COOLING CIRCUIT INSPECTION

Before removing the radiator and draining the engine coolant, inspect the cooling circuit for tightness.

- Remove the cowling. (☞ 6-6)
- Remove the radiator cap ① and connect the tester ② to the filler.

⚠ WARNING

Do not remove the radiator cap when the engine is hot.



- Give a pressure of about 110 kPa (1.1 kgf/cm², 15.6 psi) and see if the system holds this pressure for 10 seconds.
- If the pressure should fall during this 10-second interval, it means that there is a leaking point in the system. In such a case, inspect the entire system and replace the leaking component or part.

⚠ WARNING

When removing the radiator cap tester, put a rag on the filler to prevent spouting of engine coolant.

CAUTION



Do not allow the pressure to exceed the radiator cap release pressure, or the radiator can be damaged.




RADIATOR

REMOVAL


- Remove the cowling. (☞ 6-6)
- Drain engine coolant. (☞ 2-18)
- Disconnect the upper and lower radiator hoses from the radiator.




- Disconnect the siphon hose from the radiator.
- Remove the reservoir tank by removing its mounting bolt.





- Disconnect the horn lead wires.




- Disconnect the cooling fan motor and its thermo-switch lead wire coupler ①.
- Remove the radiator by removing its mounting bolts.



- With the fasteners unlocked, remove the radiator shroud ①.




- Remove the cooling fan and horn.
- Remove the cooling fan thermo-switch.




INSPECTION AND CLEANING

- Road dirt or trash stuck to the fins must be removed.
- Use of compressed air is recommended for this cleaning.



- Fins bent down or dented can be repaired by straightening them with the blade of a small screwdriver.



INSTALLATION



- Install the cooling fan and horn.


Cooling fan/horn mounting bolt:

8 N·m (0.8 kgf-m, 6.0 lb-ft)

- Install a new O-ring and tighten the cooling fan thermo-switch to the specified torque.

Cooling fan thermo-switch: 17 N·m (1.7 kgf-m, 12.5 lb-ft)

- Install the radiator in the reverse order of removal.
- Route the radiator hoses.
- Install the drain plug with a new sealing washer.
- Pour engine coolant. ( 2-18)
- Bleed air from the cooling circuit. ( 2-19)
- Install the cowlings.



RADIATOR RESERVOIR TANK

REMOVAL/INSTALLATION


- Remove the cowlings.
- Disconnect the siphone hose from the radiator.
- Remove the reservoir tank by removing its mounting bolt.
- Drain engine coolant.
- Install the reservoir tank in the reverse order of removal.
- Fill the reservoir tank to the upper level.



RADIATOR CAP

INSPECTION

- Remove the cowlings.
- Fit the cap ① to the radiator cap tester ②.
- Build up pressure slowly by operating the tester. Make sure that the pressure build-up stops at 95 – 125 kPa (0.95 – 1.25 kgf/cm², 13.5 – 17.8 psi) and that, with the tester held stand-still, the cap is capable of holding that pressure for at least 10 seconds.
- Replace the cap if it is found not to satisfy either of these two requirements.



Radiator cap valve opening pressure




Standard: 95 – 125 kPa

(0.95 – 1.25 kgf/cm², 13.5 – 17.8 psi)

WATER HOSE

INSPECTION


- Remove the cowling. (☞ 6-6)
- Any water hose found in a cracked condition or flattened or water leaked must be replaced.
- Any leakage from the connecting section should be corrected by proper tightening.



COOLING FAN


REMOVAL

- Remove the cowling. (☞ 6-6)
- Drain engine coolant. (☞ 2-18)
- Remove the radiator. (☞ 5-4)
- Remove the cooling fan.



INSPECTION


- Remove the cowling. (☞ 6-6)
- Disconnect the cooling fan motor lead wire coupler ①.
- Test the cooling fan motor for load current with an ammeter connected as shown in the illustration.



- The voltmeter is for making sure that the battery applies 12 volts to the motor. With the motor with electric motor fan running at full speed, the ammeter should be indicating not more than 5 amperes.
- If the fan motor does not turn, replace the motor assembly with a new one.

NOTE:

When making above test, it is not necessary to remove the cooling fan.




INSTALLATION

- Install the cooling fan.

Cooling fan motor mounting bolt:

8 N·m (0.8 kgf-m, 6.0 lb-ft)


- Install the radiator.
- Route the radiator hoses. (☞ 8-23)
- Pour engine coolant. (☞ 2-18)
- Bleed the air from the cooling circuit. (☞ 2-19)
- Install the cowling. (☞ 6-6)



COOLING FAN THERMO-SWITCH

REMOVAL

- Remove the cowling. (☞ 6-6)
- Drain engine coolant. (☞ 2-18)
- Disconnect the cooling fan thermo-switch lead wire coupler ①.
- Remove the cooling fan thermo-switch ②.



INSPECTION

- Check the thermo-switch closing or opening temperatures by testing it at the bench as shown in the figure. Connect the thermo-switch ① to a circuit tester and place it in the oil contained in a pan, which is placed on a stove.
- Heat the oil to raise its temperature slowly and read the column thermometer ② when the switch closes or opens.


TOOL 09900-25008: Multi circuit tester set

Tester knob indication: Continuity test (•||)

DATA Cooling fan thermo-switch operating temperature

Standard (OFF→ON): Approx. 105°C (221°F)

(ON→OFF): Approx. 100°C (212°F)




CAUTION

- * Take special care when handling the thermo-switch. It may cause damage if it gets a sharp impact.
- * Do not contact the cooling fan thermo-switch ① and the column thermometer ② with a pan.

INSTALLATION


- Install a new O-ring ①.
 - Tighten the cooling fan thermo-switch to the specified torque.
- U** Cooling fan thermo-switch: 17 N·m (1.7 kgf-m, 12.5 lb-ft)
- Pour engine coolant. (☞ 2-18)
 - Install the cowling. (☞ 6-6)



ENGINE COOLANT TEMPERATURE SENSOR


REMOVAL

- Drain engine coolant. (☞ 2-18)
- Remove the seat. (☞ 6-4)
- Remove the fuel tank right side cover.
- Remove the IAP sensor vacuum damper.
- Disconnect the engine coolant temperature sensor lead wire coupler.
- Place a rag under the sensor and remove the engine coolant temperature sensor ①.



INSPECTION

- Check the engine coolant temperature by testing it at the bench as shown in the figure. Connect the temperature sensor ① to a circuit tester and place it in the water contained in a pan, which is placed on a stove.
- Heat the water to raise its temperature slowly and read the column thermometer ② and the ohmmeter.
- If the temperature sensor ohmic value does not change in the proportion indicated, replace it with a new one.



DATA Temperature sensor specification

Temperature	Standard resistance
20°C (68°F)	Approx. 2.45 kΩ
40°C (104°F)	Approx. 1.148 kΩ
60°C (140°F)	Approx. 0.587 kΩ
80°C (176°F)	Approx. 0.322 kΩ

If the resistance noted to show infinity or too much different resistance value, replace the temperature sensor with a new one.

CAUTION

- * Take special care when handling the temperature sensor. It may cause damage if it gets a sharp impact.
- * Do not contact the engine coolant temperature sensor ① and the column thermometer ② with a pan.

INSTALLATION


- Install a new sealing washer ①.
- Tighten the engine coolant temperature sensor to the specified torque.

Engine coolant temperature sensor:

18 N·m (1.8 kgf-m, 13.0 lb-ft)

CAUTION

Take special care when handling the temperature sensor. It may cause damage if it gets a sharp impact.




- Pour engine coolant. (☞ 2-18)
- Install the fuel tank right side cover. (☞ 6-4)
- Install the seat.


THERMOSTAT

REMOVAL

- Drain engine coolant. (☞ 2-18)
- Place a rag under the thermostat case.
- Remove the thermostat case.



- Remove the thermostat ①.




INSPECTION


Inspect the thermostat pellet for signs of cracking.

Test the thermostat at the bench for control action, in the following manner.

- Pass a string between flange, as shown in the photograph.
- Immerse the thermostat in the water contained in a beaker, as shown in the illustration. Note that the immersed thermostat is in suspension. Heat the water by placing the beaker on a stove and observe the rising temperature on a thermometer.
- Read the thermometer just when opening the thermostat. This reading, which is the temperature level at which the thermostat valve begins to open, should be within the standard value.




DATA Thermostat valve opening temperature
Standard: Approx. 88 °C (190 °F)



- Keep on heating the water to raise its temperature.
- Just when the water temperature reaches specified value, the thermostat valve should have lifted by at least 8.0 mm (0.31 in).

DATA Thermostat valve lift
Standard: Over 8.0 mm at 100 °C (Over 0.31 in at 212 °F)

- A thermostat failing to satisfy either of the two requirements (start-to-open temperature and valve lift) must be replaced.




INSTALLATION

- Install the thermostat.

NOTE:


The jiggle valve **A** of the thermostat faces upside.



- Install the thermostat case.
- Tighten the thermostat case bolts to the specified torque.

ⓘ **Thermostat case bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)**

- Pour engine coolant. (☞ 2-18)





WATER PUMP

REMOVAL AND DISASSEMBLY


- Remove the engine under cover. (☞ 3-3)
- Drain engine coolant. (☞ 2-18)
- Drain engine oil. (☞ 2-13)
- Remove the right footrest.
- Disconnect the water hoses and crankcase breather hose.
- Remove the water pump case and clutch cover. (☞ 3-26)

NOTE:


Before draining engine oil and engine coolant, inspect engine oil and coolant leakage between the water pump and clutch cover. If engine oil is leaking, visually inspect the oil seal and O-ring. If engine coolant is leaking, visually inspect the mechanical seal and seal ring. (☞ 5-15)



- Remove the snap ring from the impeller shaft.
- Remove the impeller from the other side.



- Remove the mechanical seal ring ① and the rubber seal ② from the impeller.



- Remove the bearing using the special tool.


TOOL 09921-20240: Bearing remover set

NOTE:

If there is no abnormal noise, bearing removal is not necessary.

CAUTION

The removed bearing must be replaced with a new one.



- Remove the mechanical seal using the special tool.


TOOL 09921-20240: Bearing remover set

NOTE:

If there is no abnormal condition, the mechanical seal removal is not necessary.

CAUTION

The removed mechanical seal must be replaced with a new one.




- Remove the oil seal using a suitable bar.

NOTE:

If there is no abnormal condition, the oil seal removal is not necessary.

CAUTION


The removed oil seal must be replaced with a new one.



INSPECTION


BEARING

- Inspect the play of the bearing by hand while it is in the water pump case.
- Rotate the inner race by hand to inspect for abnormal noise and smooth rotation.
- Replace the bearing if there is anything unusual.




MECHANICAL SEAL

- Visually inspect the mechanical seal for damage, with particular attention given to the sealing face.
- Replace the mechanical seal that shows indications of leakage. Also replace the seal ring if necessary.




OIL SEAL

- Visually inspect the oil seal for damage, with particular attention given to the lip.
- Replace the oil seal that shows indications of leakage.



BEARING CASE

- Visually inspect the bearing case for damage.
- Replace the water pump body if necessary.




REASSEMBLY AND INSTALLATION

- Install the oil seal using the special tool.


TOOL 09913-70210: Bearing installer set


NOTE:

The stamped mark on the oil seal faces outside.




- Apply a small quantity of the SUZUKI SUPER GREASE "A" to the oil seal lip.



 **99000-25030: SUZUKI SUPER GREASE "A" (USA)**
99000-25010: SUZUKI SUPER GREASE "A" (Others)



- Install the new mechanical seal using a suitable size socket wrench.

NOTE:

On the new mechanical seal, the sealer  has been applied.




- Install the new bearing using the special tool.


 **09913-70210: Bearing installer set**


NOTE:


The stamped mark on the bearing faces crankcase side.



- Apply grease to the impeller shaft.

 **99000-25030: SUZUKI SUPER GREASE "A" (USA)**
99000-25010: SUZUKI SUPER GREASE "A" (Others)


- Install the rubber seal  into the impeller.
- After wiping off the oily or greasy matter from the mechanical seal ring, install it into the impeller.




NOTE:

The paint marked side (A) of the mechanical seal ring faces the impeller.

- Install the impeller to the water pump body.



- Fix the impeller shaft with the snap ring securely.




- Install a new O-ring (1).

CAUTION


Use a new O-ring to prevent engine coolant leakage.

NOTE:

Apply engine coolant to the O-ring (1).




- Set the impeller shaft end to the cam drive idle shaft. (☞ 3-90)
- Connect the water hoses and crankcase breather hose.
- Install the right footrest.
- Pour engine coolant. (☞ 2-18)
- Pour engine oil. (☞ 2-13)
- Install the engine under cover.




LUBRICATION SYSTEM


OIL PRESSURE

 2-31


OIL FILTER

 2-14


OIL PRESSURE REGULATOR

 3-67


OIL STRAINER

 3-29 and -85


OIL JET

 3-67, -68 and -94

OIL PUMP



 3-66 and -67



OIL PRESSURE SWITCH

 3-67 and 7-32


OIL COOLER

REMOVAL

- Remove the engine under cover. ( 3-3)
- Drain engine oil. ( 2-13)
- Disconnect the oil cooler hoses.
- Remove the oil cooler.




- Remove the oil cooler fin guard net.
- Remove the oil hoses.




INSPECTION AND CLEANING

- Inspect the oil cooler and hose joints for oil leakage. If any defect are found, replace the oil cooler and oil hoses with the new ones.
- Road dirt or trash stuck to the fins must be removed.
- Use of compressed air is recommended for this cleaning.



- Fins bent down or dented can be repaired by straightening them with the blade of a small screwdriver.




INSTALLATION


- Install a new gasket washer ①.

CAUTION


Use a new gasket washer to prevent engine oil leakage.




- Install the oil cooler.

 Oil cooler mounting bolt: 10 N·m (1.0 kgf-m, 7.3 lb-ft)

- Tighten the oil cooler hose union bolts to the specified torque.


 Oil cooler hose union bolt: 23 N·m (2.3 kgf-m, 16.5 lb-ft)



ENGINE LUBRICATION FLOW CHART

#2 CYLINDER [REAR]

#2 CYLINDER [FRONT]



ENGINE LUBRICATION CIRCUIT

